GLASAIR II-S TD ADVANCE NOTICE OF REVISION

Page C-149, FIGURE (C-108), Detail "B"; Page C--150, Step AF-1: Add after the last paragraph: NOTE: The important point to remember in placing the outboard seat belt attach angles is that they are ahead of the tapered area of the lower skin panels foam core. This is to facilitate the reinforcement procedure carried out in Step AF-2. When drilling the hole for the AN3-7A tie in bolt aft of the attach angle, be it's about 1/2" ahead of the aft shearweb and that it passes through the rear spar cap as shown in FIGURE (C-108).

Page G-97, Add this note between the first and second paragraphs in Step I-7: NOTE: Ignore the instructions concerning the seat back mounting holes at this time. Make a note at the beginning of Step AH, Page G-389, to do Step I-7 at that time while the aircraft is on its landing gear with the engine installed, to allow any static fuselage flex. This will make future removal and intallation of the seat back easier.

Page G-382, FIGURE (G-219); Page G-383, FIGURE (G-220); Page G-384, FIGURE (G-221): The Illustrations will change to show a revised Gas Spring Bracket on the canopy. Looking at FIGURE (G-219), Plan View of Canopy Frame section, the bracket is shown in gray hatch with the "blade" on the left side. The revised bracket has a reinforcement gusset added at the bottom of the bracket, 90° to the existing blade, forming an "L" as viewed in the plan view.

Page G-383, third paragraph: Add a 1 1/2" x 1 1/2" waxed aluminum piece 90° to the first piece as described for FIGURE (G-219) and (G-220). Note: (2) pieces of (2) layer precure laminate, roughened up, can be used in place of aluminum if desired. Fourth paragraph: Change "(10) 2 1/8" x 2 3/4" pieces" to "2 1/2" x 3 1/2" pieces". Fifth paragraph: Do not pre-saturate all (10) layers. Lay up the 10 layer laminate in place to properly conform to the shape required.

*Page G-346, FIGURE (G-194): The illustration will change to show snap ring retainers on the inside canopy latch assembly instead of the cotter pins shown.

NOTE:

*: Disregard if your kit was delivered with the cotter pin style retainers.



GLASAIR II-S

ASSEMBLY NAME

TD ADVANCE REVISION NOTICE

REVISION

10/13/93

VOLUME

PAGE 1 of 1