

GLASTAR SERVICE BULLETIN 17


Subject: Mislabeled cobalt naphthenate promoter and DMA accelerator

Applicability: Cobalt naphthenate [P/N 270-0135-001] and DMA [P/N 270-0135-002] shipped between 10/21//96 and 11/18/96. The following Kits are believed to have been affected: Kits #5017, 5133, 5137, 5165, 5194, 5204, 5323

Discussion: Bottles of cobalt naphthenate promoter were inadvertently labeled as DMA accelerator, and vice versa. As described in *Assembly Manual* "SECTION II: TOOLS AND TECHNIQUES," these chemicals should be used differently, and using either one in place of the other could have serious detrimental consequences.

Recommended Action: Before promoting further resin or using resin that may have been promoted with cobalt and/or DMA from the affected bottles, **check any cobalt or DMA bottles you have on hand to make sure they are labeled correctly.** The chemicals are easily distinguishable by color: **cobalt is purple and DMA is amber.** Re-label any bottle that is labeled incorrectly.

If you have promoted resin using cobalt or DMA from incorrectly labeled bottles, you should discard it. If you require replacement resin, please contact the Order Desk and refer to this Service Bulletin.

	REVISION:	DATE: 11/21/96	PAGE: 1 of 1
---	-----------	-------------------	-----------------